


Strip the insulation from the cable.



Slide the crimp sleeve over the cable and widen the screening braid.



Don't widen any existing screening film.



Slide the contact pin or contact socket as far as the dielectric on the inner conductor and crimp using the crimping pliers.



Insert the cable in the plug or socket connection until the contact pin or contact socket can be felt to engage.